

EZ-ACCESS provides premier accessibility for commercial and industrial applications.

In addition to the Fortress™ OSHA Stair System, we offer the Traverse™ Curbside Loading Ramp and the Titan™ Commercial Ramp & Stair System. Each provides code-compliant access while protecting your company from costly L&I or Workers' Compensation claims.

EZ-ACCESS is a division of Homecare Products, Inc., and through an extensive network of local authorized dealers, we serve the entire United States with quick and professional products and services.

Contact us today for solutions to commercial, industrial, and home accessibility or visit [www.ezaccess.com](http://www.ezaccess.com).



customerservice@ezaccess.com  
1.800.258.8503  
[www.ezaccess.com](http://www.ezaccess.com)



Scan the QR code with your smartphone to see product specifications.

# FORTRESS™

## OSHA Stair System

The *one step* to solve your job site OSHA access needs.

*Safe. Strong and durable. Lightweight.*

Two sizes available: 34" and 42 1/2"



### FORTRESS™ OSHA Stair System from EZ-ACCESS®



The perfect companion to your mobile modular unit.

OSHA-compliant universal system designed for safe access to mobile modular buildings, portable classrooms, temporary job sites, cargo trailers and more.

[www.ezaccess.com](http://www.ezaccess.com)



# Reduce workplace injuries and inventory with just one step.

The FORTRESS™ OSHA Stair System features a four-piece design with three-position, fully adjustable risers, and universal components for rapid, single-wrench installation. With every component weighing under 50 pounds, this durable stair system can safely be assembled by one person and can easily be expanded, reconfigured, or moved to meet changing needs. Standard configurations ship within 24 hours.

## The FORTRESS is the right step for:

### Safety and Durability

- OSHA compliant
- Built to withstand the rigors of everyday use
- Exceeds NIOSH lifting recommendations
  - Each major component weighs less than 50 lbs., allowing for safe, one-person installation
- Lightweight, welded construction using high-grade 6000 series alloy aluminum
- Three-year warranty

### Integrated Components

- Captured fasteners for platform and riser adjustment ensure fewer parts and no loose hardware
- Universal design allows for quick and easy single-wrench installation
- Folding platform handrails allow convenient transport and storage

### Adjustability

- Three-position, fully adjustable step with the highest adjustability range in the industry
- Fits most applications with quick adjustability from 23" - 34" or 27.5" - 42.5"
- Platform and riser legs adjust independently, allowing for easy leveling on the job site



Platform leg features captured fasteners and infinite adjustability range



One-step riser connection uses OSHA safety pin to lock riser to platform



Hardware-free handrails slide into platform and lock securely in place with Valco snap button

## Standard Features

- Welded, extruded riser for reinforced strength and a permanent slip-resistant walking surface
- Integrated components help to eliminate lost parts
- Made of durable, corrosion-resistant aluminum for years of maintenance-free use
- Standard configurations ship within 24-hours to help eliminate costly construction delays
- Pre-drilled anchor points on platform for convenient attachment to structure
- Variable position height range
  - 3-step adjusts from 23" - 34" (OSHA compliant at 25.5" and 34")
  - 4-step adjusts from 27.5" - 42.5" (OSHA compliant at 34" and 42.5")
- Platform handrails fold flat for easy transport and storage
- Three-year warranty
- 100% made in the USA

## Optional Features

- Oversized feet may eliminate the need for pavers in most soil conditions
- Platform with drain holes

## Specs

Part No.	FOR2334	FOR2742
Number of risers	3	4
System height adjustment	23", 25 1/2", & 34"	27 1/2", 34", & 42 1/2"
OSHA-compliant height	25 1/2" & 34"	34" & 42 1/2"
Riser height	8 1/2"	8 1/2"
Riser tread depth	9 1/2"	9 1/2"
Riser tread width	36 1/2"	36 1/2"
Platform size (W x L x H)	40" x 60" x 23"	40" x 60" x 23"
Riser handrail height*	36"	36"
Platform handrail height	42 1/2"	42 1/2"
System weight (lbs.)	101	107
Warranty	3 years	3 years
Feet dims (standard)	4" x 4" sq.	4" x 4" sq.
Feet dims (oversized, optional)	7 3/8" x 7 3/8" sq.	7 3/8" x 7 3/8" sq.

\* Measured from leading edge of step tread to gripping surface.